



## **Active Autowerke - Catalytic Converter “Break-In” Procedure**

**\*Please read before driving your car equipped with a new Catalytic Converter\***

- 1) Start the car but do not REV the engine.
- 2) Idle engine allowing the temperature to rise naturally to normal operating temperature.
- 3) Wait at least 10 minutes – then increase the speed to 2500 RPM, hold at 2500 RPM for 2 minutes.
- 4) Turn off the car and allow engine to cool down completely.
- 5) Drive lightly for 5 miles before any “hard” acceleration.

**\*This procedure is important to avoid the CEL light from coming on in error.**

Please take the time to review the necessary instructions above and if there are any questions please contact us at: [info@activeautowerke.com](mailto:info@activeautowerke.com) or 305-233-9300.