

Air Pump Simulator Installation

E36 323i-328i,M3 E39 528i 96-98 with M52 engine

- 1) Remove broken air pump
- 2) Cut off connector at air pump, it will be used to connect air pump simulator (see wiring diagram)
- 3) Remove fuel injector plastic cover on top of the engine, locate the two 02 sensor connections. Locate the black wire coming from the sensor on bank 1 and bank 2. These black wires will be connected to the yellow wires coming from the air pump simulator.
- 4) Mount the simulator in a place where there will be minimal heat.

